

2021+ Bronco Hood Tie-Down Mounted Fishing Rod Holder

Installation Guide



Step 1 – Unscrew the outward-facing trail sight accessory bolts



Using the L-Shape TP30 Torx Wrench on the outward-facing OEM screw and pressing your finger firmly on the OEM inward-facing screw unscrew and remove the OEM outward-facing screw.

Store the OEM outward facing screw somewhere safe for future use.

Parts List



- 2x M6 Hex Screws (included)
- L-shape TP30 Torx Wrench (from your bronco tools)

Step 2 – Align the new fishing rod holder on the outward trail sight bolt spaces



Enjoy!

Insert the hex screws through the fishing rod holder hole and bronco sight space, then Using your finger to firmly secure the hex screw while using the L-shape TP30 Torx Wrench on the OEM inward-facing screws and hand tighten.

Important: Do not overtighten!